Langkah 1: Buat Publisher dan Subscriber MQTT (HiveMQ)

Tools yang digunakan:

- Python (pakai paho-mqtt)
- HiveMQ public broker: broker.hivemq.com port 1883
- Topic: misal iot/edge/suhu

1A. Publisher Python Script

```
import paho.mqtt.client as mqtt
import time
import random
broker = "broker.hivemq.com"
port = 1883
topic = "iot/edge/suhu"
client = mqtt.Client()
client.connect(broker, port)
try:
  while True:
     suhu = round(random.uniform(20.0, 40.0), 2)
     client.publish(topic, str(suhu))
     print(f"Data suhu dikirim: {suhu} °C")
     time.sleep(5)
except KeyboardInterrupt:
  print("Publisher dihentikan.")
```

1B. Subscriber Python Script

```
import paho.mqtt.client as mqtt
broker = "broker.hivemq.com"
port = 1883
topic = "iot/edge/suhu"
def on connect(client, userdata, flags, rc):
  print("Terhubung ke broker")
  client.subscribe(topic)
def on_message(client, userdata, msg):
  print(f"Suhu diterima: {msg.payload.decode()} °C")
client = mqtt.Client()
client.on_connect = on_connect
client.on_message = on_message
client.connect(broker, port)
client.loop forever()
```

Langkah 2: Integrasi ke Monitoring

Tools:

• Telegraf: agen pengumpul data

• InfluxDB: penyimpanan time-series

• Grafana: visualisasi data

2A. docker-compose.yml



2B. Contoh telegraf.conf (input MQTT + output InfluxDB)

```
[agent]
interval = "10s"

[[inputs.mqtt_consumer]]
servers = ["tcp://broker.hivemq.com:1883"]
topics = ["iot/edge/suhu"]
data_format = "value"
data_type = "float"
name_override = "suhu_sensor"

[[outputs.influxdb]]
urls = ["http://influxdb:8086"]
database = "iotdb"
```

Langkah 3: Menjalankan yang telah dibuat

- 1. Buka VSCode
- 2. Buat folder proyek baru, misal: iot mqtt project
- 3. Buat dua file:
 - o publisher.py
 - subscriber.py
- 4. Install paho-mqtt:

Buka terminal dan ketik:

pip install paho-mqtt

5. Buka dua terminal di VSCode:

Terminal 1: jalankan publisher

python publisher.py

python subscriber.py

Langkah 4: Jalankan Docker Desktop

Buka Start Menu → cari Docker Desktop → klik untuk menjalankannya Atau jalankan perintah berikut di vscode:

docker compose up -d

Tunggu sampai ikon Docker di system tray berubah jadi warna hijau / ready

Langkah 5: Buka Grafana

1. Buka: http://localhost:3000

2. Login: admin / admin

3. Tambahkan Data Source:

• Type: InfluxDB

• URL: http://influxdb:8086

Database: iotdbTest & Save

Tambahkan Data Source (InfluxDB)

1. Masuk ke Gear → Data Sources → Add Data Source

2. Pilih: InfluxDB

3. Isi konfigurasi:

URL: http://influxdb:8086

o Database: iotdb

o HTTP Method: GET

Leave Username & Password kosong (karena tidak pakai auth)

4. Klik Save & Test

Buat Dashboard untuk Sensor Suhu

- 1. Masuk ke + → Dashboard → New dashboard → Add visualization
- 2. Di panel query (bagian bawah):

- Pilih Data source: pastikan InfluxDB yang sudah dibuat sebelumnya
- 3. Di query area:
- Measurement: suhu_sensor (pakai name_override di telegraf.conf)
- Field: biasanya value (jika data format = "value" di telegraf.conf)
- Pilih Aggregation: misalnya mean() atau last()
- 4. Ubah visualisasi jadi Line Chart (default-nya biasanya Line)
- 5. Klik tombol Apply

Berikut screenshot dari hasil yang telah dikerjakan:

(Install paho-mqtt)

```
PROBLEMS OUTPUT DEBUG CONSOLE TERMINAL PORTS

PS C:\Users\arel\Documents\Bootcamp\Bootcamp\Cloud_Engineer_Batch1\Mini Project\iot_mqtt_project> pip install paho-mqtt

>>

Defaulting to user installation because normal site-packages is not writeable

Collecting paho-mqtt

Downloading paho_mqtt-2.1.0-py3-none-any.whl.metadata (23 kB)

Downloading paho_mqtt-2.1.0-py3-none-any.whl (67 kB)

Installing collected packages: paho-mqtt

Successfully installed paho-mqtt-2.1.0
```

(python publisher.py)


```
PROBLEMS
           OUTPUT
                    DEBUG CONSOLE
                                     TERMINAL
                                               PORTS
Data suhu dikirim: 20.79 °C
Data suhu dikirim: 22.13 °C
Data suhu dikirim: 21.85 °C
Data suhu dikirim: 35.78 °C
Data suhu dikirim: 37.93 °C
Data suhu dikirim: 29.21 °C
Data suhu dikirim: 38.31 °C
Data suhu dikirim: 23.72 °C
Data suhu dikirim: 34.22 °C
Data suhu dikirim: 20.81 °C
Data suhu dikirim: 38.42 °C
Data suhu dikirim: 33.84 °C
Data suhu dikirim: 24.21 °C
Data suhu dikirim: 38.55 °C
Data suhu dikirim: 27.78 °C
Data suhu dikirim: 24.18 °C
Data suhu dikirim: 30.07 °C
Data suhu dikirim: 20.46 °C
Data suhu dikirim: 21.76 °C
```

(python subscriber.py)


```
PROBLEMS
           OUTPUT
                    DEBUG CONSOLE
                                     TERMINAL
Suhu diterima: 35.06 °C
Suhu diterima: 28.66 °C
Suhu diterima: 21.82 °C
Suhu diterima: 22.8 °C
Suhu diterima: 35.32 °C
Suhu diterima: 31.92 °C
Suhu diterima: 22.32 °C
Suhu diterima: 28.8 °C
Suhu diterima: 23.37 °C
Suhu diterima: 38.18 °C
Suhu diterima: 20.43 °C
Suhu diterima: 38.11 °C
Suhu diterima: 35.74 °C
Suhu diterima: 22.25 °C
Suhu diterima: 35.95 °C
Suhu diterima: 24.85 °C
Suhu diterima: 26.95 °C
Suhu diterima: 22.08 °C
Suhu diterima: 36.57 °C
```

(docker compose up -d)

(Docker Desktop)



(Data Source (InfluxDB))



(Grafana Dashboard untuk Sensor Suhu)

